
## **SELF-DRILLING**

## #1 Drill Point, Spaced Thread

## 



Description	A drill point that is15 - 35% shorter than a #2 drill point of the same nominal diameter.
Applications/ Advantages	A #1 drill point is neccesary in rare occasions when the nominal length of the entire fastener is so short that a stan- dard #2 point would not allow for a sufficient number of threads to engage the material it has drilled.
Material	AISI 1016 - 1024 or equivalent steel

## INDUSTRIA www.asmc.net